


**Owners manual** 

LJ300T-18A



### **PREFACE**

You have purchased our scooter, congratulations and thank you for putting your trust in us.

This model is a sturdy scooter in modern design.

Its sound construction, the meticulous selection of materials, the advanced manufacturing techniques and conscientious work of dedicated employees provides the scooter with all the characteristics such as economical operation, quality, reliability and its lasting value.

We cannot be held liable for any consequential damage caused by accessories not approved by the factory.

The scope of delivery and version of the scooter is solely determined by the purchase agreement concluded with the dealer.

This operating manual includes important in structions for handling your light scooter. Read it carefully, because professional handling combined with regular care and maintenance helps to maintain the scooter's value and is one of the requirements for warranty claims.

We wish you at all times a safe journey.

Yours

Safety symbols and notes

## Please observe the following:



Precautionary measures against the risk of accidents, injury and /or death.




The vehicle is equipped with a catalyst, this results in extremely high temperatures on the exhaust system(risk of burning)



Important instructions and precautionary rules to avoid damage to the vehicle. Nonobservance can lead to the warranty becoming void.



Special instructions for better handling during operation, inspection adjustments and service activities.



## CONTENTS

OVERVIEW AND OPERATION	RIDING INSTRUCTIONS	
Identification number, engine number3	Ride safely	18
View of vehicle4-5	Ride economically and environmentally	19
Instrument, handlebar instrument6-10	Running-in instructions	20
Ignition lock and fork-column lock11-12	Starting	21
Storage box, luggage hooks13	Brakes	22-23
Fuel, fuel tank14	Stopping the engine	23
Tank cap15	SERVICE INSTRUCTIONS	
Side stand, parking stand16	Servicing the scooter / cleaning agents	
SAFETY TEST	Winter operation and corrosion protection  Repairing paint damage / servicing the tyres	
Checklist17	Zay-up commission	26
Load and lights18	Technical modifications, accessories and spare parts	27

## CONTENTS

## **NOTES ON MAINTENANCE**


Engine oil, Transmission oil	.28-29
Regulating valve, Drive belt, roller, Precautions for engine maintenance	ce30
Checking steering bearing, telescopic fork	31
Tyres	32
Front wheel brake	.33-34
Rear wheel brake	35-36
Adjusting the play of the twist grip throttle control	37
Cleaning the air filter	.38-40
Cleaning the spark plug	41
Fuse	42
Battery	.43-44
Changing the light bulbs	.45-54
Adjusting the headlight	55
Fault diagnosis tester	56-57

## **TECHNICAL DATA**

Engine	58
Power transmission	59
Chassis	59
Lubricants and operating fluids	60
Electrical equipment	60
Dimensions and weights	61
WARRANTY AND SERVICE DATA	
Warranty conditions	62
List of wear items	63-64
Inspection plan	65-67
Proof of maintenance	68-69
Circuit diagram	70

## **SUMMARY AND OPERATION**

## Identification number



## Chassis number



## Engine number



NOTE

The description for right-hand side is viewed from the driver.

The identification number (1) is located on the frame below the right side cover.

The VIN locates in the rear part of luggage box (2).

The engine number (3) is located on the Rear side of the left crankcase.

## Key

With the scooter you get two separate indefinite keys for:

This scooter is only equipped with one remote key.

- Ignition lock, Fuel tank cap and storage box.

Keep the spare key at a safety place.

## Right-hand side view

- 1 Storage box with tool kit
- 2 Battery box and fuse
- 3 Ignition and fork-column lock
- 4 Brake fluid container for front wheel brake
- 5 Handbrake lever for front brake
- 6 Spark plug



## Left-hand side view

- 7 Handbrake lever for rear brake
- 8 Instrument
- 9 Tank cap
- 10 Air filter
- 11 Engine oil filter cap
- 12 Parking stand
- 13 Side stand



### **LCD Combination Instrument**



Turn on the scooter every time, the scooter will initialize automatically:self-inspection and all signal lights on, the pointer swings and turn to zero. If the pointer didn't move, please go to dealer to check.

### 1. Oil pressure warning indicator

When this indicator light is on, it means the oil pressure is abnormal, then stop the engine and check it.

### 2. ABS warning indicator

this indicator will be on. When the speed exceeds 5KM/H, this indicator should go off. If the indicator is on when the vehicle is running, it means the ABS anti-lock system is malfunctioning, please contact the after-sales service to deal with it.

### 3. Left turn indicator

Blinks at the normal frequency when the left turn signal indicator is turned on.

### 4. Position indicator

The indicator comes on at the same time when the position indicator light is turned on.

## 5. Water temperature symbol

When the indicator light flashes, the engine water temperature is high, there are abnormalities, at this time should stop to cool down and check.

## 6. EFI warning indicator

When the vehicle is powered on and parked, When the vehicle is in the power state, if the engine does not start, the indicator light is on. Then, when the engine starts, the indicator light is off. The above situation shows the condition of the EFI system is working correctly. If the engine starts, the warning indicator remains on all the time. Please contact the after-sales or authorized dealer if this light goes on all the time.

## 7. High beam indicator

When the high beam is on, this light will be on at the same time

### 8. Right turn indicator

Blinks at the normal frequency when the right turn signal indicator is turned on.

## **Multi-function Meter**



## 1. Engine coolant temperature indicator

Shows the engine water temperature value in real-time.

## 2. Time display

Shows the current time. It can be adjusted by SET and SEL buttons, see page 8, SET and SEL button function description for details.

## 3. Handlebar heating display

When the handlebar heating is on, the symbol "OFF" turns to "ON" and the color turns to orange.

## 4. Tire pressure alarm indicator

When the front tire pressure is lower than 170Kpa or higher than 290Kpa, or the rear tire pressure is lower than 170Kpa or higher than 340Kpa, this indicator will light up, please stop and check.

## 5. Rear tire pressure display

Shows the rear tire pressure value in real-time.

## 6 Front tire pressure display

Shows the front tire pressure value in real-time.

### 7. Signal display (if applicable)

## 8. Atmospheric temperature display

Shows the current temperature.

### 9. Engine speed display

## 10. Fuel gauge display

Shows the fuel level in the tank. Eight cells indicate full fuel. The low fuel goes on when there is only one bar that remains and blinks, go refuel the fuel tank immediately.

### 11. Total mileage (single mileage) display

Shows the total mileage of the vehicle, or the mileage of the vehicle at one time. The total mileage and single mileage display can be adjusted by the SET and SEL buttons, see page 8, SET and SEL button descriptions for details.

### 12. Vehicle speed display

Shows the real-time speed of the vehicle

## **Key Function Description**



## 1. SET key

Shortpress SET key, for the total subtotal switch.

Longpress SET key, for the enter clock date setting.

### 2. SEL key

Short press SEL key, for metric, and English system switch.

Long press SEL key, for subtotal down, subtotal clear.

### Clock setting


Long press SET key to enter, at this time s-hort press SET key cursor shift, short press SEL key to adjust the blinking bit value, af-ter adjustment, press SET key to save and exit.

## Tire pressure matching

Within the 20S after power on, long-press the left and right keys to enter the tire pressure matching selection state, then the motorcycle icon flashes, this interface long-press the left and right keys 2S to exit tire pressure matching.


In the tire pressure matching selection state, short press the left or right keys corresponding (left or right) tire pressure value flashes. During single tire matching, press and hold the left and right buttons at the same time for 1S to stop the current tire pressure matching and return to the tire pressure matching selection status, then you can select the front and rear wheels again. When the individual tire pressure matching is finished, it will also return to the tire pressure matching selection status.

## Handlebar instrument, left





Handlebar instrument, right




- 1 Fixed grip
- 2 Handbrake lever for rear brake
- 3 PASS Passing light switch
- 4 High beam indicator
  - ≣D high beam
    - low beam
- 5 🛦 hazard warning lamp switch
- 6 Direction-indicator switch

  - Switch to left Left indicator on
  - Switch to right Right indicator on Push button for switch off

- 7 > Push-button:horn
- 8 Handlebar heating key
- (1) After the vehicle starts, press the key, the handlebar will be in the heating state. Heating contains three grades, in the working state, each time you press the button, the faster the heating speed. The indicator colors in turn: green, yellow, red.
- (2) When the battery voltage is too low or too high, the controller enters the protection state and cuts off the output. The indicator light flashes a few times into the standby state.


- 9 Handbrake lever for front brake
- 10 Throttle
- 11 Engine off switch
  - $\bigcirc$  When the switch on"  $\bigcirc$  " position, it has electric power, the engine can be start.
  - $\bowtie$  When the switch on"  $\bowtie$  " position, it is not power, the engine can not be start.

## Handlebar instrument, right




- 12 When the lock is in the "ON" position, press the button to open the seat cushion.
- 13 (5) Starter button

### Ignition and fork-column lock







## Keyless ignition switch

to vehicle, the PKE function activates.Press down the keyless ignition switch, the green Indicate light on switch will be on, turn the switch to control the vehicle.

A. Turn off the engine and electric circuit.

- B. Turn on the electric circuit, engine is ready to start.
- C. Press down the switch, follow the direction G. Press this button on the remote key, remof arrow and turn to the position, lock the ha- ote unlock the vehicle. The green indicate li-
- D. Turn to this position, press the "SEAT" button to open the luggage box; press the "F-UEL" button to open the fuel tank cap.

E. Press this button on remote key, the vehi-When the remote key is within 1.5 meters cle seeking function activates, then all turn lights flash.

- F. Press this button on remote key,turn lights flash one time, PKE function activates; press this button again, PKE function close and switch to energy saving mode, then can't turn on the vehicle even the remote key is within 1.5 meters to vehicle.
- ght will on, turn the ignition switch to control the vehicle without press down.

### Note:

- 1. This model has an emergency braking and turn signal flashing alarm function. Once the speed exceeds 50km/h and the deceleration speed reaches the set value within a short period of time, the turn signal flashing alarm will alert the vehicle behind.
- 2. This model has an anti-theft alarm function. When the vehicle is powered down for 10 seconds, it will automatically enter the set-up function. At this time, if the key is 1.5m away from the vehicle and the vehicle is subjected to vibration caused by an external force, the vehicle horn will sound 8 times continuously and the turn signal flashes 10 times for alarm prompting.

### Ignition and fork-column lock





Remark: red wire to positive pole and green wire to negative pole, not in opposite way.

Caution: The wiring is only used when the battery is dead. When opening the seat, do not try to use the wiring to start the vehicle, and do not connect the positive and negative terminals wrong, otherwise, it will blow the fuse, or even burn the vehicle.

### Remark:

1. When the remote key is out of battery, put the key close to the position shown In the picture to unlock the vehicle. Change the battery of remote key in time.

2. If keep the vehicle in storage for long time, the battery could be out of power and can't open the luggage box, please do as the following instruction to connect external battery to open the luggage box. Follow the direction of arrow in picture 1 to open the battery cover, connect external battery to the 2 wires as picture 2. Please pay attention that the red wire connects to positive pole of battery and green wire to negative pole of battery. Then open the luggage box as instruction. (detail in page 8)

## Storage box



- Do not store valuables in the box.
- Make sure that the seat has been locked completely after it was pressed down.
- Take out valuables before washing to avoid wetting these objects.
- Do not place thermal sensitive objects in the box because of engine's heat and high temperature.



### Unlock

- Turn ignition switch to "SEAT FUEL" (1), press button "SEAT"(2), open the seat cushion (3).

## Lock

- Press down the seat (3) until the lock is engaged.

Never leave the key in the storage box.

## **⚠** WARNING

After the seat is closed check if it was locked firmly! -Risk of accidents!

Maximun load capacity: 10 kg

## Storage/power outlet



- Storage is for small stuff.
- When the vehicle turn on, the 12V power (4) outlet works, it can connect to low voltage equipment, such like mobile phone, GPS, etc.

# **CAUTION**

Maximum load capacity: 1.5 kg Do not transport bulky loads.

## Fuel, fuel tank

## **⚠** WARNING

Fuel is highly inflammable and can explode. Do not smoke or bring a naked flame near the fuel tank.

Fuel expands under the influence of heat and the sun. Therefore, never fill the tank to the brim. Never fill the tank while the engine is running.

Never bring a glowing cigarette or naked flame near an open tank, because fuel vapour could suddenly ignite.

## Fuel stock, tanking



# NOTE

The fuel indicating (1) is active when the ignition is turned on.

The scale with the tank symbol | remembers for a tank stop.

E = Empty

F = Full

Don't run down the fuel tank until it is empty.


### Filling up with fuel

- Use only premium lead-free fuel
- Use fuel containing up to 5% ethanol by volume (E5) Unleaded fuel min. 95 Octane.

## Tank cap







NOTE

The fuel tank cap is next to battery box.

## Unlock:

- Main stand
- Turn the ignition switch to "SEAT FUEL" (1), press "FUEL" (2), open the fuel tank cap (3).
- Turn the tank cap (4) counter-clockwised and open the tank cap.

## LOCK:

- Align A to B, press the tank cap and turn it clockwised, Until a green point appear on the cover.



Fuel

- Use fuel containing up to 5% ethanol by volume (E5)

Unleaded fuel min. 95 Octane

## Side stand and parking stand







Propping up the scooter on the side stand.

## **⚠** WARNING

Always make sure that the stand is resting on firm ground. On sloping roads, always park the scooter facing uphill.

It is essential that the side stand is folded up before starting off! -Risk of accid- - Put your left hand on the left-hand handleents!

### Side stand



The scooter is equipped with a side stand switch. If the side stand is folded up the engine is shut off and will not start.

- Switch off the engine.
- Hold with your right hand the holder grip
- Fold out the arm fo the side stand(1)as far forward as it will go and stop by foot.
- Slowly tilt the scooter to the left until its weight is supported.

## Parking stand

- Switch off the engine.
- Put your left hand on the left-hand handlebar grip.
- Hold with your right hand the holder grip(3).
- Push the parking stand (2) down until the two skids are on the ground.
- Put you full body weight on the operating mandrel of the main standard.
- Pull the scooter towards the rear and simultaneously upwards onto parking stand.
- Check that the scooter is standing firmly.

## Checklist

Before each ride, carry out a safety check Before starting your ride, check the followiusing the checklist.

Take the safety check seriously. Carry out maintenance activities before you start your - Steering (smooth and free play) ride or ask a specialized dealer to do so. This will provide you with the certainty that your motorcycle corresponds to traffic requlations. A technically faultless motorcycle is a basic requirement for the safety of both yourself and other road users.

- Engine oil quantity
- Fuel quantity
- Front brake
- Rear brake
- Tyres (profile and pressure)
- Telescopic fork
- Load / lights
- Total weight
- Lights
- Brake fluid (lever)
- Brake (operation)

In case of problems or difficulties, contact a dealer, who will do everything possible to assist you.

## **⚠** WARNING

While the engine is running or the ignition is on, do not touch the ignition syst-

# FIRE HAZARD

The exhaust system becomes very hot. While riding, idling or parking, make sure that to inflammable materials (e . g . hay, leaves, grass, coverings or luggage,etc.) can come into contact with it!

### SAFETY TEST

## Load / lights



## **⚠** WARNING

For the sake of your safety, use only original accessories or products released by us.

We cannot judge for each third-part product whether it can be safely used in combination with your scooter.

Nor can a official approval give such a guarantee in all cases, since the test scope is not always sufficient.



Our accessories and approved products as well as qualified advice are available from all specialized dealers.

## Correctly loaded

- Make sure that the left-right weight distribution is balanced.
- Check that fastenings are correct and tight.
- Do not transport bulky loads.
- Do not cover the lights.

# **⚠** WARNING

The total allowable weight may not be exceeded.

Check the tyre pressure.

## Checking the lights



## **⚠** WARNING

Before any ride, check the operation of all lighting components.

- Check that the headlamps and lenses are clean.

## Ride safely



# **M** CAUTION

Riding safety is largely also determined by the manner of riding.

### Therefore:

- Put on a tested / approved safety helmet and correct close the buckle.
- Wear suitable protective clothes.
- Rest your feet on the footrests.
- Do not ride if your riding ability has been compromised.

Your reactions can be adversely affected not only by alcohol, but also by drugs and medicines.

- Strictly observe all traffic regulations.
- Always adapt your riding speed to the traffic and road conditions.

On smooth, slippery roads take into account that your riding stability and braking power are limited by the grip of the tyres on the road top.

### RIDING INSTRUCTIONS

## Ride economically and be aware of the environment

Fuel consumption, environmental pollution. Turn the engine off when waiting in trand wear of engine, brakes and tyres depend on various factors.

Your personal riding style is highly determinant for economical fuel consumption and exhaust gas and noise generation.

While idling, the engine takes a long time to warm up to operational temperature. In the warm-up phase.however.the wear level and pollutant emissions are very high. It is therefore best to start riding immediately after start-up.

### Avoid rapid acceleration

Open the throttle not further than needed,in order to reduce fuel consumption as well as pollution and wear levels.

Do not use excessive revs; change up as soon as possible and do not change down until it is necessary to do so.

## Ride as evenly as possible and look ahead as far as possible.

Unnecessary acceleration and hard braking cause high fuel consumption and increased pollution levels.

affic.

Different riding conditions affect fuel consumption. The following conditions are unfavourable for fuel consumption:

- High traffic density, especially in big cities with many stops for traffic lights.
- Frequent short rides with repeated starts and warm-ups of the engine.
- Riding in a column of motorcycles at low speed, meaning riding with relatively high revs.

Plan rides ahead of time in order to avoid heavy traffic.

Fuel consumption is also affected by conditions that are out of your control, for instance, poor road condition, hills, riding in winter.

Observe the following aspects for economical fuel consumption:

- The planned inspection intervals must be closely observed.
- Regular service by a specialized. dealer will guarantee not only continued operability, but also economical fuel consumption, low environmental pollution and a long lifespan.
- -Check the tyre pressure every two weeks.

Low tyre pressure increases rolling resistance. This increases fuel consumption and tyre wear and adversely affects riding behaviour.

- Continually check fuel consumption.
- Frequently check the engine-oil level.

### RIDING INSTRUCTIONS

### Running-in

Running-in instructions for engine and transmission.



## CAUTION

Excessive revs while running-in the engine increases the wear of the engine. Engine faults during the running-in period must be immediately reported to a specialized dealer.



During the running-in period, ride in frequently changing load and rpm ranges. Select winding and slightly hilly routes. Avoid constantly low rpm counts and full throttle under load.

- During the first 500 km: Less than 1/2 throttle.
- Up to 1.000 km: Less than 3/4 throttle.



# **CAUTION**

The first inspection must be carried out immediately after the first 1.000 km.

You can save yourself delays by making an appointment with a specialized dealer in advance.

## Running-in new tyres



## **⚠** CAUTION

New tyres have a smooth surface. They must therefore be roughened by carefully running them in at various slanted po-

Only then will the surface obtain its full grip!

Running-in new brake linings


## **⚠** WARNING


New brake linings must be run-in and will not have their full friction power until after 500 km.

The slightly reduced braking effect can be compensated for by an increase in the pressure on the brake lever. During this period, avoid unnecessary hard braking actions.

## Starting with the electric starter







## ⚠ WARNING

Propping up the scooter with the parking stand. Operate the rear handbrake lever to avoid a moving of the scooter.

Avoid high engine rpm's while the vehicle is standing still, otherwise the clutch will engage.



Every scooter is equipped with side stand switch. When the side stand is fold up, can start the engine. When the side stand is released, can't start the engine.

When the key turn to" \(\Omega\) "position, please wait 2-3 seconds. When the fuel pump star to work fuel in tube reach standard pressure. then turn on engine.

## Before starting

- Propping up the scooter with the parking
- Turn the ignition lock (1) with the ignition key to its operating position" ○ ".
- Right switch(3) at " ∩ "position.
- Do not open the throttle (5).
- Pull and hold the handbrake lever (2)or(6).
- Operate the start button (3) (4).
- If the engine can not be started after the starter motor is running for 3-5 seconds. open the throttle(5)1/8-1/4 turns and start again.
- Push the scooter off its parking stand.
- Mount the scooter.
- Release the brake before riding.

## **M** CAUTION

If the engine won't start immediately, release the start button, wait a few seconds and push it again. Each time, push the start button for just a few seconds in order to save the battery. Never push the start button for more than 10 seconds.

## **⚠** WARNING

Never allow the engine to run in an enclosed space. Exhaust gases are highly toxic and can kill.

### RIDING INSTRUCTIONS

### **Braking**

### Wet brakes

Washing the scooter or riding through water or rain can delay the braking effect due to wet or (in winter) ice-covered brake discs and linings.



## **⚠** WARNING

The brakes must first be operated until they are dry.

## Salt film on the brakes

When riding on salted streets without braking for a while, the full braking effect may be delayed.

## Oil and grease

## **⚠** WARNING

The brake discs and linings must be free of oil and grease!

If the scooter is not used for a while, a rust film may form on the brakes and thus increase the braking effect. A thick rust film can cause the brakes to lock up. When setting out on a ride after a long Iay-up period, carefully operate the brakes several times until they work normally.

## **⚠** WARNING

Operate the brakes to grind off the salt deposited on the brake discs.

### Dirty brakes

When riding on dirty streets, the braking effect can be delayed due to dirty brake discs and linings.

## ⚠ WARNING


Operate the brakes until they are clean. Lining wear is increased by dirty brakes!




Make sure you practice braking for emergency situations, but do so where you will not pose a risk to yourself or others(e.g.a deserted parking area).

## RIDING INSTRUCTIONS

## Braking





## Stopping the engine



### **Braking**

d independently from each other.

The front brake is operated via the right-hand brake lever(1)on the handlebars, and the rear brake is operated via the left-hand brake lever(2).

throttle gas and operate both brakes at the same time.

On tight curves, sandy / dirty streets, wet a- - Turn the ignition lock (3) with the ignition The front brake and rear brake are operate- sphalt and icy roads, use the front brake carefully: if the front wheel locks, the bike will - Pull out the ignition key. slide sideways.

Brake with care.Locked wheels do not have much braking effect and can lead to skidding / crashing. In principle,do not brake on a curve, but before the curve.

When stopping or slowing down,release the Braking on a curve increases the danger of

- key to the position" X ".
- Take away the remote control key.

## Servicing the scooter / cleaning agents





Regular, expert service will help maintain the value of your scooter and is a condition for guarantee claims for corrosion and other such damage.



# **M** CAUTION

Rubber and plastic parts will be damaged by caustic or penetrating cleaning agents or solvents.





## **⚠** WARNING

Always carry out a brake test after cleaning and before starting a ride!



# **CAUTION**


Do not use steam or high-pressure jet de-

Such devices can damage seals, the hydraulic braking system and the electrical system.

## **CLEANING**

- To wash the motorcycle, use a soft sponge and clean water.
- Afterwards, dry off with a polishing cloth or chamois.
- Do not wipe off dust or dirt with a drycloth, to avoid scratching the paint or covering.

### Servicing the scooter / cleaning agents



## **CAUTION**

Never use paint-polishing agents on plastic parts.

- After a longish ride, thoroughly clean the chassis and the aluminium parts and preserve them with a commercially available anti-corrosion agent.

## Operation in winter and anti-corrosion protection



Protect the environment by using only environmentally friendly preservation agents, and use them frugally.

Use of the motorcycle in the winter can cause considerable damage due to the presence of salt on the roads.



## CAUTION

Do not use hot water, which would increase the effect of the salt.


- At the end of each ride, wash the motorcycle with cold water.
- Thoroughly dry the motorcycle.
- Treat parts liable to corrosion with waxborne anti-corrosion agents.

## PRESERVATION AGENTS

When necessary, the scooter must be preserved with commercially available preserving and cleaning agents.

- By way of precaution (especially in winter), regularly treat parts liable to corrosion with preservation agents.

## Repairing paint damage



Minor paint damage should be immediately repaired.

### Servicing tyres

If the scooter is not used for a longer period, it is recommended to support the scooter so that its weight is not on the tyres.

You can prevent the tyres from becoming dry and brittle by spraying them with a siliconerubber treatment. First thoroughly clean the

Do not store the scooter or the tyres in hot spaces (such as a boiler room) for longer periods.

## **⚠** WARNING

A minimum tyre-profile depth of 2.0 mm must be maintained at all times.

## Lay-up / commission

### Lay-up

- Clean the scooter.
- Remove the battery.
- Observe the maintenance instructions.
- Spray suitable lubricants onto the brakelever and clutch-lever joints and the sidestandard and main-standard bearings.
- Rub bright / chromium-plated parts with acid-free grease(Vaseline).
- Store the scooter in a dry room and jack it up so that its weight is not on the wheels.



Combine lay-up / commission activities with an inspection by a dealer.

## Commission

- Remove the preservation agents from the outside.
- Clean the motorcycle.
- Install the charged battery.
- Preserve the battery terminals with terminal grease.
- Check / adjust the tyre pressure.
- Check the brakes.
- Carry out activities according to the inspection plan.
- Carry out the safety checks.

Technical changes, accessories and spare parts



## **⚠** WARNING

Technical changes to the scooter can lead to cancellation of the EC operating license.

Should you want to make technical changes, observe our guidelines. This will serve to prevent the scooter from being dam-aged and the traffic and operational safety being retained. A specialised dealer can carry out these activities with meticulous care.

Always consult a dealer before buying accessories or making any technical changes.



# **M** CAUTION

We recommend using only approved accessories and original spare parts for our scooter.

This is in your own interests: the safety, suitability and reliability of these accessories and parts will have been tested specifically for the scooter.

Although we keep track of the market, we cannot evaluate nor be held liable for the quality of non-approved accessories and parts, even if they have a certificate of acceptance from an officially recognised technical testing / supervision agency, or a license issued by the authorities.

For approved accessories and original spare parts, see a specialised dealer. He will also ensure that they are professionally installed.

## Engine oil







## Checking the oil level

## **M** CAUTION

Checking the oil while the engine is cold will lead to a wrong measurement and therefore the wrong oil quantity. In order to avoid engine damage, never exceed the maximum oil level nor let it drop below the minimum level.



Make sure that the scooter during oil-level checks stands level in all respects. Even the slightest inclination towards the side will produce measurement errors.

- Stop the warmed-up engine, wait for approx. 5 minutes and hold the scooter up-right.
- Propping up the scooter on the parking st-
- Stop the engine and remove the oil filler cap (1) on the lower right of the crank-case.
- Clean the oil filler cap at the MIN-MAX aera with a clean rag.



## CAUTION


For checking the oil level only insert the oil filler cap and don't screw in! Otherwise there will be a wrong measurement in order to avoid engine damage.

- The oil level must be between the minimum and maximum marks.
- Tighten the oil filler cap by hand.

If required, replenish the engine oil SF 5W/ 40 via the oil level up to the MAX level mark.

- When change new engine oil, open the oil hole screw (2), till all engine oil is flow out, then tighten the screw (2) and add new oil via the oil level up to the MAX. level mark.
- Tighten the oil filler cap (1).

## Engine oil







## **M** CAUTION

Do not use additives . Since the oil also serves to lubricate the clutch, do not use car engine oils supplemented with friction modifiers (such energy-conserving oils can lead to the clutch slipping). Use a suitable, light engine oil for scooters, such as Motorex SAE 5W/40 mineral oil API (SF or higher).

- If required, replenish the engine oil(for classification and viscosity, see the table) via the oil-filler opening up to the maximum level marking.

## Recommended grade:

Per API:SF or higher or also with additional release status: ACEA A3/96 (CCMC G5)

Recommended viscosity:


Viscosity depends on the outside temperature. For short while, the temperature may exceed or fall short of the limits of the SAE grades.

The recommended viscosity grade SAE 5 W/40 covers the ambient temperature range -15°C to +40°C and therefore represents the optimum for out latitudes.

## Checking the transmission oil level

- Stop the warmed-up engine, wait for approx. 5 minutes.
- Propping up the scooter on the parking st-
- remove the oil filler cap (1) and check if the oil level is below the oil-filler opening.
- If required, replenish transmission oil Hypoid SAE 85W-90 via the oil-filler opening.
- When change new transmission oil, open the oil hole screw(2),till all transmission oil is flow out, then tighten the screw (2) and add new oil via the oil-filler opening.
- Tighten the oil filler cap(1).

### Regulating valve



- When checking the valve clearance, the valve gear phase marker must be aligned according to the above instructions.
- Use the thickness gauge to check whether the clearance between the valve and the adjusting gasket conforms to the specified value. If the inlet and exhaust valve clearance is different from the specified value below, loosen the locknut as shown in the figure and adjust the valve clearance.

Inlet valve(not started and state of cooling): 0.10mm

Exhaust valve (not started and state of cooling): 0.15mm



Correct assembly: from the inside out, all the rollers are placed in the position shown in the picture. The exposed iron surface is on the right side and the plastic wrap surface is on the left side.

## Drive belt, roller

- It is recommended that 6000 km first check whether the transmission belt ball slider is damaged.
- Belt detection:
- Standard Value: 21.3±0.2mm:
- Limit use width: 19.5mm;
- Limit use crack: Tear to core wire position;
- More than 10,000 km can be replaced belt;
- Driving wheel detection:
- Ball standard diameter: ¢ 21±0.1mm。
- Nylon slider opening ≥ 4.7mm need to change.
- It is recommended that 12,000 to 15,000 km of ball be replaced.
- Ball replacement assembly requirements (must be assembled according to this requirement).

### Precautions for engine maintenance

- 1. When starting the engine, the throttle should be gently operated to start the engine for 30-60s, and then the cooler should be moderately opened to start the engine. Do not accelerate immediately after starting, and accelerate after 1-3min of running.
- When starting by pedal, the starting time should not exceed 5s (excluding auxiliary time). The starting lever should be able to bounce back flexibly after pressing.
- 3. During electrical start-up, the starting time should not exceed 5s, and the starting time should be 10 seconds apart. If the starting time cannot be started for 5 consecutive times, then need check for no fault. It is strictly prohibited to press the starting button after starting.
- 4. After the engine starts normally, Idle running for 3 -5 seconds. Let the engine lubricate before driving, At the same time, attention should be paid to avoid high speed and heavy load operation before the engine is preheated.
- 5. The new machine is mounted on the motorcycle after the first 1,000 kilometers of driving, It cannot operate at high speed for long periods of time, nor can it rotate beyond its maximum speed of 80. Do not operate the throttle valve in full open condition, after 500 kilometers, a repair should be carried out to compensate for the slight wear and tear in the run-in period,
- so as to ensure the good performance of the engine. 6. Clean the oil /gas separator and check and clean the air filter every 2000 km, the main purpose is to remove the oil stored in the oil and gas separator, check the sealing condition of each binding surface of the air filter, and remove the sand and dust on the air filter chamber and filter element. When assembling, pay attention to the sealing of each joint face, and replace or repair the parts that have lost the sealing function to ensure the air filtration effect, prolong the service life of the engine piston block, effectively avoid burning oil or power shortage.

## Checking the steering bearings



# NOTE

The telescopic fork should not jam up when turned and it should swing back lightly to both end positions.

- Pull the hand brake to block the front wheel brake.
- Hold the handlebar with both hands and try to move the handle bar(1)back and forth.

If the fork column bearing shows noticeable play, it must be adjusted by a specialised dealer.

## Checking the telescopic fork

- Pull the hand brake to block the front wheel brake.
- Now pump the fork girders (2) several times up and down using the handlebar.
- The suspension should respond perfectly.
- Check the fork girders for oil leaks.



If damage to the telescopic fork or the spring strut is found have the motorbike examined by a professional dealer.

## **ABS** maintain instruction (for ABS version only)

Turn on the bike every time, the ABS instruction light on the speedometer is on, this is normal. When the speed reach 5Km/H, the ABS instruction light will be off, ABS works properly. If the ABS system is wrong, the ABS instruction light will be on during ride. Then check the ABS, like if the ABS plug-in to wire harness is loose, is the gap between ABS wheel speed sensors and gear rings 0.5mm and 1.5mm, if the surface of wheel speed sensors adsorb small metal pieces. After fixation of ABS faults, the instruction light on speedometer will be off when speed is 5Km/H and up. If the problem still exists, contact your dealers for service.

## Tyre profile



## Checking the tyre profiles

## **⚠** WARNING

Observe the minimum profile depth prescribed by law.

Never ride without valve caps(1). Firmly tightened valve caps prevent the tyre from suddenly losing pressure.

- Measure the profile depth at the centre (2) of the tyre's tread.

Recommended minimum profile depth:

2.0 mm

Observe the wear marks(3).



## Checking the tyre pressure

## **⚠** WARNING

Adjust the tyre pressure according to the total weight load. Never exceed the rated total weight or the bearing capacity of the tyres.

Incorrect tyre pressure will have a considerable effect on the riding properties of the scooter and the lifespan of the tyres.

- While the tyres are cold:
- Twist off the valve caps.
- Check / adjust the tyre pressure.
- Twist on the valve caps.

Tyre pressure

Front: 2.00Kg/cm<sup>2</sup> Rear: 2.25Kg/cm<sup>2</sup>



## Tyre size

The standard scooter is provided with the following tyre sizes:

Front 110/70-13 M/C 48S or 55L or 48P Rear 130/70-13 M/C 57S or 63S or 63P

All Tyres are tubeless.


# **⚠** WARNING

Use only tyres approved by the manufacturer. The use of non-approved tyre brands, types or sizes leads to the operating permit of the vehicle becoming null and void. Use only pairs of tyres produced by the same manufacturer.

### Front wheel brake



### Front brake-fluid tank



### **⚠** WARNING

Sudden changes in play or a spongy feel of the brake lever (1) can be caused by faults in the hydraulic system.

Do not ride on when in doubt about the operability of the brake system. Immediately consult a dealer.

### Checking the brake-fluid level

### **⚠** WARNING


Every two years, the brake fluid must be changed by a dealer. The level must not drop below the MIN mark. Use only brake fluid of the DOT 4 classification.

# CAUTION

Do not spill any brake fluid on painted or plastic surfaces as it will demage the surface severely.

- Turn the handlebars until the brake-fluid tank (2) is level.
- The brake fluid level(3)should be between the minimun (MIN) and the maximum marking (MAX).
- If air bubbles can be seen, check the brake linings for wear; if necessary, replenish the brake fluid by a dealer.

### Front wheel brake



Checking the brake linings



# **CAUTION**

The minimum lining thickness must be maintained



For your own safety, we recommend having activities to the brake system carried out by a dealer.

- Check the thickness of the brake lining.

Minimum thickness: A = 2.0 mm

- If the lining thickness is below the minimu- - Check the thickness of the disc. m, have the brake lining (1) replaced by a dealer.




### Checking the disc brake

- Visually inspect the disc (2).

Minimum thickness: **B = 4.0 mm** 

- If the disc thickness is below the minimum, have the disc (2) replaced by a dealer.

### Rrar wheel brake(For disk brake)





### **⚠** WARNING

Sudden changes in play or a spongy feel of the brake lever (1) can be caused by faults in the hydraulic system.

Do not ride on when in doubt about the operability of the brake system. Immediately consult a dealer.

### Checking the brake-fluid level

### **⚠** WARNING


Every two years, the brake fluid must be changed by a dealer. The level must not drop below the MIN mark. Use only brake fluid of the DOT 4 classification.

# **CAUTION**

Do not spill any brake fluid on painted or plastic surfaces as it will demage the surface severely.

- Turn the handlebars until the brake-fluid tank (2) is level.
- The brake fluid level(3)should be between the minimun (MIN) and the maximum marking (MAX).
- If air bubbles can be seen, check the brake linings for wear; if necessary, replenish the brake fluid by a dealer.

### Rear wheel brake



Checking the brake linings



# **CAUTION**

The minimum lining thickness must be maintained




For your own safety, we recommend having activities to the brake system carried out by a dealer.

- Check the thickness of the brake lining.

Minimum thickness: A = 2.0 mm

- If the lining thickness is below the minimu- - Check the thickness of the disc. m, have the brake lining (1) replaced by a dealer.




### Checking the disc brake

- Visually inspect the disc (2).

Minimum thickness: **B = 4.5 mm** 

- If the disc thickness is below the minimum, have the disc (2) replaced by a dealer.

### Adjusting the play of the twist grip throttle control





### Check:

- Check the throttle cable for light move-ment by turning the twist grip(1)from closed to open position.
- Move the handlebar to check whether the throttle cable moves freely.
- Check whether the throttle cable is obstructed by other parts.
- Open the twist grip throttle control until resistance can be felt.
- Measure the play. Nominal value: A = 1-2 mm

### Adjustment:

- Push back the protective cap (2).
- Slacken the lock nut (3) on the handlebar.
- Turn the setscrew (4) accordingly.
- Tighten the lock nut (3).
- Check the play.
- Push over the protective cap (2).

# NOTE

If the play cannot be corrected this way, have the scooter checked by your dealer.

### Cleaning the air filter








### Check and change



Check or change the spark plug only when the engine is cold.

- Turn ignition switch to "SEAT FUEL" (1), press button "SEAT"(2), open the seat cushion (3).

- Remove the two screw (4) and open the battery cover (5).
- Remove the socket head cap screw (6) and remove the miscellaneous box (7).




### Cleaning the air filter





### Replaceing the air filter



NOTE

The scooter is attached with a oil foam air filter. In case of heavy dirtiness the foam has to be replaced.

Disassembly and cleaning

- Remove the clamp(1)from the carburettor.
- Remove the screws (2) and take off the air filter (3).





The scooter is attached with a oil foam air filter. In case of heavy dirtiness the foam(3) has to be replaced.

Disassembly and cleaning

- Use cross screws (4) and take off the air air filter cover (5).
- Remove the foam (6).
- Clean the foam with Motorrex air cleaner.
- Afterward soak and wring out the foam with air filter oil.

### Cleaning the air filter





### Checking the spark plug



- Remove the foam (6).
- Clean the foam with Motorrex air cleaner.
- Afterward soak and wring out the foam with air filter oil.

### Installation



- Usually the installation takes place in reverse order to disassembly.

### **M** CAUTION

Never run the engine without air filter.

- Dust deposit is one of the major causes of reducing output horsepower and increasing fuel consumption.
- Change the air cleaner element more frequently to prolong the engine's service life if the scooter is ride on dusty roads very often.
- Check for properly installation of the foam housing in the filter case.
- Otherwise the engine runs poorly or lead to serious engine damage.
- Be careful not to soak the air cleaner when washing the scooter. Otherwise it will cause engine hard to start.

### Check and change



### **M** CAUTION


Check or change the spark plug only when the engine is cold.

- Turn the switch to the "SEAT FUEL" position (1) and press "SEAT"(2) Open the seat cushion (3).
- Remove the two screw (4) and open the battery cover (5).
- Remove the socket head cap screw (6) and remove the miscellaneous box (7).
- Pull the spark plug connector (8).
- Unscrew the spark plug with the spark wrench from the on-bord toolkit.

### Checking the spark plug








- Check the electrode gap (0.6-0.7mm) rep- Installation takes place in reverse order to lace the spark plug if it is severely burnt a- disassembly.
- Use a new spark plug **NGK CR8EKB** and
- Screw in the spark plug by hand and then tighten up with the spark wrench.

Torque 11 Nm.



41

### Checking the fuse







# **CAUTION**

Never install a fuse with a larger rating, since this could destroy the entire electrical system.

The fuse is located behind the inspection cover.

- Turn ignition switch to "SEAT FUEL" (1), press button "SEAT"(2), open the seat cushion (3).
- Remove the two screw (4) and open the battery cover (5).
- Open the fuse case (6) and remove the fuse.
- A faulty or blown fuse must be replaced by a new one.



- Check the fuse for correct contact. Loose fuse will blow.



Installation takes place in reverse order to disassembly.

### **Battery**



### ♠ WARNING

Always wear safety glasses. Keep children away from acids and batteries.



### A EXPLOSION DANGER

A battery being charged produces a highly explosive gas, which is why fire, sparks, naked flames and smoking are prohibited.



# **⊗** FIRE HAZARD

Avoid generating sparks and electrostatic discharges when handling cables and electrical devices.

Avoid short circuits.



### **DANGER-CAUSTIC ACTION**

Battery acid is highly caustic, so always wear safety gloves and glasses. Do not tilt the battery as acid can leak from the ventilation openings.



# FIRST AID

If acid comes into contact with an eye,immediately flush the eye for several minutes with fresh water. Then immediately visit / call a d-

Acid on the skin or clothing must immediately be neutralised using acid converter or soap suds, and the spots must be flushed with plenty of water.

If acid is swallowed, immediately visit / call a doctor.



### CAUTION

Do not expose batteries to direct sunlight. Discharged batteries can freeze, so they must be stored in a place where the temperature remains above 5-15C. Professional maintenance.charging and storage will increase the lifespan of the battery and are a condition for the honouring of guarantee claims.



Take a dead battery to a collection point. Never dispose of one with household refuse.

### Charging the battery

After a long lay-up(3-4 months), charge the battery. The charging current (in amperes) must not exceed 1/10<sup>th</sup> of the battery capacity (Ah).

The battery must not be fast-charged. The battery may only be charged using a special charger approved for MF batteries.


#### Maintenance

Although the battery is maintenance-free. Never leave the battery discharged. Keep the battery clean and dry and make sure that the connection terminals are firmly seat-

### Checking the fuse







# **CAUTION**

The battery may only be connected or disconnected while the ignition is inactive.

First disconnect the minus terminal (6, black cable).

Then disconnect the plus terminal (7, red cable).

When installing the battery, first connect the plus terminal (7, red cable).

The battery is maintenance-free. Do not try to open it.

- Turn ignition switch to "SEAT FUEL" (1), press button "SEAT"(2), open the seat cushion (3).
- Remove the two screw (4) and open the battery cover (5).
- Disconnect the battery.
- Remove the battery.

Installation takes place in reverse order to disassembly.



### Headlights/front left and right turn signals







### Changing the bulb



Use only tested,incandescent bulbs with the 'E' designation. Use of non-approved bul-bs will void the operating license. Do not touch the bulbs with bare fingers. Hold bulbs with a clean, dry cloth when installing or removing them.


Low beam-high beam bulb: 12V 9W 12V 13.5W

Position light bulb: **12V 1.8W** 

ove the windshield (2). - Remove the screws (3)(4) and remove the


headlight shield (5).


Front turn signal light bulb: 12V 1.44W



### Headlights/front left and right turn signals







- Remove screws (6)(7)(8), unplug connectors (9) (10), windshield bracket, and front panel (11).

- Remove the bolts (12), open the fuel tank cover, remove the screws (13), open the left and right side storage box covers, remove the screws (14), unplug the front left and right turn signal connectors (15), and remove the left and right front side covers.



### Headlights/front left and right turn signals



- Remove the screws (16) and replace the front left and right turn signals as needed.



- The light source of the front left and right turn signals is LED, and the whole lights need to be replaced.





### Headlights/front left and right turn signals





- Remove the bolt(17) (18) and unplug the headlight connector (19).
- Remove the screw (20) and replace the front left and right headlights as needed.



- If the light source of the left and right headlights is LED, the whole headlights need to be replaced.

Installation takes place in reverse order to disassembly.






### Rear direction indicator/tail/brake lamp/rear registration plate lamp







### Changing the lamp



Do not touch the bulbs with bare fingers. Hold bulbs with a clean, dry cloth when installing or removing them.

- The rear direction indicator/tail/brake lamp is LED.


Please change the whole lamp.

Rear direction indicator/tail/brake lamp bulb: LED 12V 1.44W/6.4W/9.5W


rear registration plate lamp


bulb: **LED 12V 0.5W** 


- Turn the switch to the "SEAT FUEL" position (1) and press "SEAT"(2) Open the seat cushion (3).
- Remove the two screw (4) and open the battery cover (5).
- Remove the socket head cap screw (6) and remove the miscellaneous box (7).



### Rear direction indicator/tail/brake lamp/rear registration plate lamp








- ear armrest (9).
- Remove the screws (8) and remove the r- Remove screws (10) (11) (12) (13) and remove the rear side cover assembly.

### Rear direction indicator/tail/brake lamp/rear registration plate lamp









- Remove screws (10) (11) (12) (13) and remove the rear side cover assembly.

### Rear direction indicator/tail/brake lamp/rear registration plate lamp










- Remove the bolts (14) and remove the rear fender assembly.

### Rear direction indicator/tail/brake lamp/rear registration plate lamp









- Unplug the rear taillight connector (15), re- Remove the screws (17) and replace the move the screws (16),and remove the rear rear taillight. center cover, rear left, and right side covers.
- Unplug the rear license plate light connector, remove the screws (18) and nuts (19), and remove the rear fender aluminum bracket.

### Rear direction indicator/tail/brake lamp/rear registration plate lamp







- Remove the nut (20) and replace the rear right and left turn signals.
- Remove screws (21) and remove the lower section of the rear mudguard (22).
- Remove the screws (23) and replace the rear license plate light.
- The rear tail light, rear left and right turn signal light, and rear license plate light are LED lights, the entire lightsneed to be replaced.

Installation takes place in reverse order to disassembly.

### Check the headlamps



### Adjusting the headlamps



# NOTE

If you have problems adjusting the headlamps, see a specialised dealer. An incorrect adjustment is punishable by law. Remember, you are responsible for the correct adjustment of the motorbike's headlamp.

### **⚠** WARNING

Do not run the engine in an enclosed space (risk of asphyxiation).

Position the motorcycle on a level floor 5 m (measured from the headlamp) from a light coloured wall with a rider seated on the motorcycle and the tyres filled at the correct pressure.

- Measure the distance from the floor to the centre of the headlamp and mark the height on the wall with a cross. Draw a second cross 12 cm beneath the first cross.

- Start the scooter and run the engine.
- Activate the dipped beam.
- Adjust the bolt (1) for the vertical and horizontal angle of the illuminated surface area of the road top for the headlamp.

### Fault diagnosis tester






1. Turn ignition switch to "SEAT FUEL" (1), press button "SEAT"(2), open the seat cushion (3).



3. Fault diagnosis tester connector (6).



4. Fault diagnosis tester (7).



2. Remove the two screw (4) and open the battery cover (5).



5. Right switch(8) at " \(\Omega\) "position.

### Fault diagnosis tester





6. The ignition key(9) at " \(\cap \) "position.

7. Side (10) switch at horizontal position.

# **⚠** WARNING

When connect the fault diagnosis tester, right switch(8), ignition key(9) must be at " \(\infty\)" position, side stand (10) at horizontal position.

	LJ300T-18A
Engine type	LJ1P75MN
Construction:	One cylinder 4-stroke petrol engine
Pistion displacement:	278cm³
Bore:	φ 75 mm
Stroke:	63 mm
Compression ratio:	11.0:1
Cooling:	Water cooling
Maximum net power output:	18.0 kW at 8000rpm
Maximum net torque:	25.0 Nm at 5750rpm
Fuel consumption:	3.3 L/100km
CO <sub>2</sub> emissions:	75 g/km
Ignition system:	Transistorized ignition system with electronic ignition control (ECU)
Spark plug:	NGK CR8EKB
Electrode gap:	0.7-0.8 mm
Fuel supply:	EFI
Idle speed:	1700±150 r/min
Air-filter:	Oil filter air filter
Typ of starter:	Electric starter

Power transmission	
Clutch:	Centrifugal type
Transmission:	CVT
Chassis	
Scooter version:	LJ300T-18A
Front suspension:	Telescopic fork
Rear suspension:	Unit swing, hydraulic shock absorption, adjustable preload
Wheels front:	Light metal (Alu) MT $3.0 \times 13$ or Net wheel MT $3.0 \times 13$
Wheels rear:	Light metal (Alu) MT $3.50 \times 13$ or Net wheel MT $3.5 \times 13$
Tires front:	110/70-13 M/C 48S or 55L or 48P tubeless
Tires rear:	130/70-13 M/C 57S or 63S or 63P tubeless
Tire pressure:	Front: 2.00Kg/cm <sup>2</sup> Rear: 2.25Kg/cm <sup>2</sup>
Brakes, front:	Disc brake φ 240 mm,hydraulic
Brakes, rear:	Disc brake φ 220 mm, hydraulic

Lubricants and operating fluids	
Fuel tank capacity:	13.5±0.1 Liter
Fuel:	Use fuel containing up to 5% ethanol by volume: E5. Unleaded fuel min. 95 Octane
Engine oil:	SAE 5W 40 mineral oil API(SF or higher)
Filling quantity:	1.3 liters
Transmission oil:	Hypoid-oil SAE 85W-140 or SAE 80W-90 GL5
Filling quantity:	0.25 litres
Electrical Equipment	
Generator:	12V 361W
Battery:	12V 10Ah
Fuse:	20A 15A 10A 5A
Head light:	Dipped beam/High beam 12V 9W/12V 13.5W
Position light:	12V 1.8W
Instrument lights Speedometer:	12V 0.2W
Control lights indicator and high beam:	12V 0.01W
Brake/rear light:	12V 9.5W/12V 6.4W
Front turn signal light:	12V 1.44W
Rear turn signal light:	12V 1.44W

Dimensions and weights	
Overall length:	1940 mm
Width across handlebars:	780 mm without rear view mirror
Maximum height:	1330/1270 mm without rear view mirror
Wheel base:	1390 mm
Seat height:	800 mm
Weight in running order:	169 kg
Max. permitted total weight:	329 kg
Top speed:	120 km/h

#### WARRANTY

### Warranty conditions

In case of an occurring fault we will provide the customer with the following performances through the authorized dealer (seller) within the scope of its statutory warranty obligations:

- 1. Within warranty period, we will rectify any deficiencies caused by material or manu- 3. The warranty does not cover normal wefacturing faults through the authorized dealer (seller) by repairing or replacing the affected part according to the statutory warranty regulations. We may deny the requested repair or replacement of the fau-Ity part if this would only be possible with disproportionately high costs. In this case we rectify the deficiency through the authorized dealer (seller) by applying the other possible type of subsequent fulfillment. If both types of subsequent fulfillment are only possible with unproportionately
- high costs, we deny the subsequent fulfi-Ilment all-together through the authorzied dealer (seller). The customer is then entitled to legal claims. Replaced parts pass over into the possession of us.
- 2. The installation of spare parts within the scope of warranty does not extend the warranty period that has started with the date of delivery of the motorcycle.
  - ar and tear caused by normal use as we-Il as wear and tear caused by inappropriate handling and inappropriate use. Oxidation and corrosion are caused by environmental influences and are also not covered under warranty.
  - 4. Warranty claims lodged by the cuistomer will be rejected in case of: Manipulations to the motorcycle, installation of a different exhaust system, changes to the gearbox or secondary transmission ratio and

- installation of accessories or spare parts which have not been approved by us. Repairs carried out in workshops not authorized by us and the non-compliance with the maintenance intervals in the workshop of an authorized dealer will also cause the rejection of warranty claims.
- 5. When lodging a warranty claim the customer must present the correctly filled in service book to the seller.
- 6. The following table gives the customer an overview of the average limits of the respective wear parts.

### WARRANTY

### List of wear parts

Wear parts	Wear limits
Tires, houses, rims	depending on riding style, load and tire pressure the wear limit may already be reached after only 500 km or even earlier.
Wheels, hubs	depending on riding style, load and tire pressure the wear limit may already be reached after only 1500 km or even earlier. Check during each maintenance. Oxidation is a lack of maintenance!
Oils, air filter, leakage inspection on engine	during the first inspection, then with every maintenance interval(every 3000 km/6000 km). Check oil level before every ride.
Spring fork, spring strut	Cleaning / inspection during every maintenance.
Lamps, incandescent bulbs, electric system	depending on road conditions / unevenness of the road surface the lifetime will be reduced, this may already occur after 500 km.
Barke linings, brake shoes, brake lines	depending on riding style and load these may already be worn after 1500 km, in cross-country operation even earlier.
Sedal rings, sealants, O-rings	must be replaced during each maintenance interval to ensure proper function.
Radial seals on engine, gearbox, fork and wheels	depending on road conditions and care wear may start after 500 km. Dirt reduces the lifetime. Do not clean with a high pressure cleaner!
Wheel bearings, steering bearings	depending on road conditions and care wear may start after 1500 km. Soiling of the wheel hub reduces the lifetime. Check during each maintenance interval, do not clean with a high pressure cleaner!
Swing arm bearing	depending on load and care after 1500 km, check with every maintenance.
Cables	depending on care starting after 500 km. Check with every maintenance.
Coverings	Plastic parts will be damaged by caustic or penetrating cleaning agents or solvents.

### WARRANTY

### List of wear parts

Wear parts	Wear limits
Air cleaner, oil filter	with each maintenance interval.
Starter battery, batteries, fuses, starter brushes	depending on ambient temperatures failures can be expected in the 6th month, when used for short rides even earlier.
Mirror glasses	depending on ambient temperatures and care failures can be expected in the 6th month, in winter operation even earlier. Oxidation is a lack of maintenance!
Bowden cables,brake cables,throttle cables	depending on use and care from the 6th month
Self-locking nuts, cotter pins locking plates bonded screw connections	during each maintenance interval or after unscrewing the nut or unlocking the lock.
Variomatic, CVT, rolls, belts	depending on riding style and load these may be worn after 500 km.
Clutch linings / friction discs	depending on riding style and load these may be worn after 500 km.
Pistons, cylinders, crankshaft, conrods, engine bearings	depending on riding style, load and care these parts may be worn after 200 hours. When riding mainly with full throttle even earlier.
Spark plug	with each or every second maintenance interval.
Exhaust system, inspection of mountings	depending on use and care from the 6th month, in winter and short distance operation even earlier. Oxidation is a lack of maintenance!

Please observe the following:

- During and after the warranty period all inspections should solely be performed by a specialised dealer approved by us.
- Observe the inspection intervals and have the specialised dealer confirm them on the guarantee certificate.
- Use only original spare parts.



### **CAUTION**

In case of non-compliance the warranty will become null and void.

The various activities carried out are listed on the inspection plan.

During the warranty period the following inspection intervals must be complied with:

1.000 km (1st service) Every 3.000 km / or after 6 months Every 6.000 km / or after 12 months

After the warranty period the inspection intevals specified in this manual must be applied as follows:

Every 3.000 km / 6 months Every 6.000 km / 12 months

### **⚠** WARNING

For safety reasons, do not carry out any repair or adjustment activities to the scooter and chassis that exceed a closely restricted scope. Tinkering with safetyrelevant parts could threaten the safety of yourself and third parties.

This applied especially to the exhaust system, carburettor, ignition system, fork column, brake system and lights.

Before starting work on the electrical system, disconnect the minus terminal of the battery.

### **INSPECTION PLAN**

### Checking and maintenance

The follow chart show the kilometers for maintenance. When reach the kilometer, it must follow the instruction to check and make maintenance. Turning system, engine, electronic system, side stand and wheels are key important parts. It is necessary to have a professional technician to handle.

The symbol means: I: checking, clean, adjust C: clean R: change A: adjust L: lubrication T: tight

Maintenance period		Odometer (KM) (Remark 2)															
Maintenance content	300	1000	2000	3000	4000	5000	6000	7000	8000	9000	10000	11000	12000	13000	14000	15000	Everyday check before riding
Oil for crankcase	F	R Every 2000km R											I				
Oil filter and oil net	(	0						E	very 20	000km	С						
Oil gas separator		Every 2000km I, C															
Air filter(Remark 1)		Every 4000km clean filter, Every 5000km replace the filter element															
Fine filter								E	very 60	000km	R						
Drive belt							1				R						
Driving wheel ball							- 1				R						
Spark plug		- 1			ı				- 1				- 1				
Valve clearance		I			I				- 1				- 1				
Brake pedal		I	- 1	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Brake oil		Ev	ery 2 y	ears o	r 30000	Okm ch	ange.	The bra	ke flui	d must	be cha	nge aft	er it tu	rns bla	ck.		I

### **INSPECTION PLAN**

Maintenance period		Odometer (KM) (Remark 2)															
Maintenance content	300	1000	2000	3000	4000	5000	6000	7000	8000	9000	10000	11000	12000	13000	14000	15000	Everyday check before riding
Friction disc					ı				- 1				- 1				
Brake system		I. A			I. A				I. A				I. A				
Brake					I				ı				ı				
Front headlight beam adjustment					I				ı				I				
Clutch		ı			ı				ı				I				
Stand					ı				- 1				- 1				
Suspension					I				I				- 1				
Screw/bolt/fasteners (Remark 3)		I							I								
Wheel(Remark 3)		ı			ı				ı				I				
Turning system		I											- 1				
Cooling fluid						I					I					I	

- \* When the mileage is over the highest on the table, please perform according to the period set on the table.
- \* Driving on dusty place, it is recommended to clean it frequently.
- \* Often drive on bad road condition, make the maintenance and service more frequently.

### MAINTENANCE CONFIRMATION

1.000 km/1 months 1st service dealer stamp:	After 3.000 km/6 months dealer stamp:	After 6.000 km/12 months dealer stamp:	After 9.000 km/18 months dealer stamp:
km	km	km	km
date	date	date	date
After 12.000 km/24 months	After 15.000 km/30 months	After 18.000 km/36 months	After 21.000 km/42 months
dealer stamp:	dealer stamp:	dealer stamp:	dealer stamp:
km	km	km	km
date	date	date	date

### MAINTENANCE CONFIRMATION

New brake fluid		New brake fluid	New brake flui	id	New brake fluid		
Yes no		Yes no	Yes	no	Yes	no	
kmdate		kmdate	km date		kmdate		
Stamp, signature		Stamp, signature	Stamp, signati	ure	Stamp, signatu	re	

# Circuit diagram Sillings B 6/Y B A A 3 2 1 A B C D A B C D When the straight extent A B C D After engen sersor 70