



High/Low Beam Switch

L	●	●	●
L	●	●	●
L	●	●	●
L	●	●	●

Turning Light Switch

L	●	●	●
L	●	●	●
L	●	●	●
L	●	●	●

Left switch

W	●	●	●
G	●	●	●
O	●	●	●
L	●	●	●
Y	●	●	●
Lg	●	●	●
C	●	●	●

Ex-light (front right)

Lb	●	●	●
W	●	●	●
G	●	●	●
Y	●	●	●
O	●	●	●

Front Brake Switch

B	●	●	●
G/Y	●	●	●
B	●	●	●

Speedometer

O	●	●	●
Y/W	●	●	●
W/L	●	●	●
B	●	●	●
Bt/R	●	●	●
Y	●	●	●
G	●	●	●
L	●	●	●
Lb	●	●	●
R	●	●	●

Ignition

R/W	●	●	●
B	●	●	●
Bt/W	●	●	●
C/R	●	●	●

Starting Switch

O/B	●	●	●
Y/R	●	●	●

Starting Switch

O/B	●	●	●
Y/R	●	●	●

- 1 +
- 2 K-line
- 3 CRANK-
- 4 CRANK+
- 5 Gnd
- 6 Coi1
- 7 02 heater
- 8 ASD
- 9 ACT3
- 10 GND Sensors
- 11 5V Sensors
- 12 Speed-in
- 13 LAMP MIL
- 14 TPS
- 15 Sensor 02+
- 16 NTC engine
- 17 ACT2
- 18 ACT1