



12V 7Ah battery

starting relay

Starting Motor Assy

Turning light (rear right)

Turning light (rear left)

License plate lamp (5W)

Tail Light

brake light

Start valve

K-line

Side Stand Switch

Sensor Fuel

Oxygen sensor

TPS sensor

Cylinder temperature sensor

ignition coil

- 1 +
- 2 K-line
- 3 CRANK-
- 4 CRANK+
- 5 Gnd
- 6 Coil1
- 7 02 Heater
- 8 ASD
- 9 ACT3
- 10 GND Sensors
- 11 5V Sensors
- 12 Speed-in
- 13 LAMP-MIL
- 14 TRS
- 15 Sensor 02+
- 16 MTC engine
- 17 ACT2
- 18 ACT1

IDLE-Sol1

AUX-Sol1

Main-Sol1

USB

relay

Ignition

Starting Switch

Light switch

Starting Stop switch

Ignition

Ignition

Starting Switch

Stop switch

Controller

Rectifier

Magneto

Electric horn

Trigger

Flasher

Trumpet switch

Turning Light Switch

High/Low Beam Switch

Left switch

Turning light (front right)

Headlight 35W/35W

Ex-light

Turning light (front left)

Rear Brake Switch

Front Brake Switch

Fuel

Speedometer

Ignition

Ignition

Starting Switch

Light switch

Starting Stop switch