

S. No	Fault code	Description of DTC	Fault Class	Active MIL
1	P 0118	Engine Coolant Temperature Sensor Circuit High / Open Circuit	1	√
2	P 0117	Engine Coolant Temperature Sensor Circuit Low	1	√
3	P 0116	Engine Coolant Temperature Sensor signal performance	2	√
4	P 1116	Engine Coolant Temperature Sensor signal out of range	2	√
5	P 0335	Crankshaft Position Sensor "A" Circuit	1	√
6	P 2301	Ignition Coil "A" Primary Control Circuit High	1	√
7	P 2300	Ignition Coil "A" Primary Control Circuit Low / Open Circuit	1	√
8	P 0123	Throttle Position Sensor/Switch "A" Circuit High	1	√
9	P 0122	Throttle Position Sensor/Switch "A" Circuit Low / Open Circuit	1	√
10	P 0232	Fuel Pump circuit short High	1	√
11	P 0231	Fuel Pump circuit short Low / Open Circuit	1	√
12	P 0601	Internal Control Module Memory Checksum Error	1	√
13	P 0262	Cylinder 1 Fuel Injector "A" Circuit High	1	√
14	P 0261	Cylinder 1 Fuel Injector "A" Circuit Low / Open Circuit	1	√
15	P 0108	Manifold Absolute Pressure Sensor Circuit High	1	√
16	P 0107	Manifold Absolute Pressure Sensor Circuit Low/Open Circuit	1	√
17	P 3106	Manifold Absolute Pressure Sensor rationality at low TPS	2	√
18	P 0105	Manifold Absolute Pressure Sensor signal stuck	2	√
19	P 0113	Intake Air Temperature Sensor Circuit High / Open Circuit	1	√
20	P 0112	Intake Air Temperature Sensor Circuit Low	1	√
21	P 0111	Intake Air Temperature Sensor signal stuck	2	√
22	P 0114	Intake Air Temperature Sensor Circuit Intermittent	2	√
23	P 0132	O2 Sensor Circuit High Voltage Bank 1 Sensor 1	1	√
24	P 0131	O2 Sensor Circuit Low Voltage Bank 1 Sensor 1 / Open Circuit	1	√
25	P 2195	O2 Sensor Signal Lean at PE Bank 1 Sensor 1	2	√
26	P 014D	O2 Sensor Slow Response - Lean to Rich Bank 1 Sensor 1	3	√
27	P 014C	O2 Sensor Slow Response - Rich to Lean Bank 1 Sensor 1	3	√
28	P 0031	O2 Sensor Heater Control Circuit Low Bank 1 Sensor 1 / Open Circuit	1	√
29	P 0032	O2 Sensor Heater Control Circuit High Bank 1 Sensor 1	1	√
30	P 00D1	O2 Sensor Heater current low Bank 1 Sensor 1	2	√
31	P 00D3	O2 Sensor Heater current low Bank 2 Sensor 1	2	√
32	P 0301	Cylinder 1 Misfire Detected	3	√
33	P 0500	Vehicle Speed Sensor "A" Circuit	2	√
34	P 0505	Idle air control system error	2	√
35	P 0562	System Voltage Low	1	√
36	P 0563	System Voltage High	1	√
37	P 0420	Catalyst System Efficiency Below Threshold Bank 1	3	√
38	P 013B	O2 Sensor Slow Response - Lean to Rich Bank 1 Sensor 2	2	√
39	P 2A01	O2 Sensor Circuit Range/Performance Bank 1 Sensor 2	2	√

40	P 00D2	HO2S Heater Control Circuit Range/Performance Bank 1 Sensor 2	2	√
41	P 1037	O2 Sensor Circuit High Voltage Bank 1 Sensor 2	1	√
42	P 1038	O2 Sensor Circuit Low Voltage Bank 1 Sensor 2	1	√
43	P 1137	HO2S Heater Control Circuit Low Bank 1 Sensor 2	1	√
44	P 1138	HO2S Heater Control Circuit Low Bank 1 Sensor 2	1	√